



Triax

TD54 - TD64 - TD78 - TD88




Assembly and mounting instructions
Montageanleitung
Notice de montage
Montagevejledning







1







2




3




4




19.2° E - ASTRA



13° E - EUTELSAT



5° E - Sirius



1° W - Thor, Intelsat

